

SCPI User Manual

SDG1000 Series Function/Arbitrary Waveform Generator

SDG1005/SDG1010/SDG1020/SDG1025/SDG1050

Declaration

Copyright © SIGLENT Technologies Co., Ltd. All rights reserved.

Contents in this Manual are not allowed to be copied, extracted and translated before being allowed by SIGLENT Company

Catalogue

Introduction to the SCPI Language	1
1.1. About Commands & Queries	1
1.1.1. How they are listed?	1
1.1.2. How they are described?	1
1.1.3. When can they be used?	1
1.1.4. Command Notation	1
1.2. Table of Commands & Queries	3
1.3. IEEE 488.2 Common Command Introduction	4
1.1.5. CHDR	4
1.1.6. OPC	4
1.1.7. IDN	5
1.4. Output Command	6
1.5. Basic Wave Command	7
1.6. Modulate Wave Command	9
1.7. Sweep Wave Command	13
1.8. Burst Wave Command	15
1.9. Parameter Copy Command	18
1.10. Arbitrary Wave Command	18
1.11. Phase Command	20
1.12. Sync Command	20
1.13. Configuration Command	21
1.14. Buzzer Command	21
1.15. Screen Save Command	21
1.16. Clock Source Command	22
1.17. Frequency Counter	22
1.18. Store list command	24
1.19. Get arbitrary wave data command	25
1.20. Virtual key command	27
1.21. Index	28

Introduction to the SCPI Language

1.1. About Commands & Queries

This section lists and describes the remote control commands and queries recognized by the instrument. All commands and queries can be executed in either local or remote state.

The description for each command or query, with syntax and other information, begins on a new page. The name (header) is given in both long and short form at the top of the page, and the subject is indicated as a command or query or both. Queries perform actions such as obtaining information, and are recognized by the question mark (?) following the header.

1.1.1. How they are listed?

The descriptions are listed in alphabetical order according to their short form.

1.1.2. How they are described?

In the descriptions themselves, a brief explanation of the function performed is given. This is followed by a presentation of the formal syntax, with the header given in Upper-and-Lower-Case characters and the short form derived from it in ALL UPPER-CASE characters. Where applicable, the syntax of the query is given with the format of its response.

1.1.3. When can they be used?

The commands and queries listed here can be used for SDGxxxx Series digital instruments.

1.1.4. Command Notation

The following notation is used in the commands:

< > Angular brackets enclose words that are used placeholders, of which there are two types: the header path and the data parameter of a command.

:= A colon followed by an equals sign separates a placeholder from the description of the type and range of values that may be used in a command instead of the placeholder.

{ } Braces enclose a list of choices, one of which one must be made.

[] Square brackets enclose optional items.

... An ellipsis indicates that the items both to its left and right may be repeated a number of times.

1.2. Table of Commands & Queries

Short	Long Form	Subsystem	What Command/Query dose
*IDN	*IDN	SYSTEM	Get identification from device.
*OPC	*OPC	SYSTEM	Get or set the OPC bit (0) in the Event Status Register (ESR).
CHDR	COMM_HEADER		Set the format of return data (Long, short, off)
BSWV	BASIC_WAVE	SIGNAL	Set or get basic wave parameters. Turns on or off channel signal.
ARWV	ARBWAVE	Data SYSTEM	Change arbitrary wave type.
BUZZ	BUZZER	SYSTEM	Set or get buzzer State.
SCFG	SYSTEM_CONFIG	SYSTEM	Set or get power on initializing parameter way
ROSC	ROSCILLATOR	SIGNAL	Set or get clock source.
MOD	MODULATION	SIGNAL	Set or get modulated wave parameters.
OUTP	OUTPUT	SIGNAL	Set or get output state.
CHCP	CHANNEL_COPY	SIGNAL	Copy parameters from channel one to channel two, or from channel two to channel one.
INVT	INVERT	SIGNAL	Set or get output signal phase state.
SCSV	SCREEN_SAVE	SYSTEM	Set or get screen save State.
SWE	SWEEP	SIGNAL	Set or get sweep wave.
SYNC	SYNC	SIGNAL	Set or get in-phase signal.
BTWV	BURSTWAVE	SIGNAL	Set or get burst wave parameters.
MDWV	MODULATEWAVE	SIGNAL	Set or get modulate wave parameters.
STL	STORE_LIST	SIGNAL	Get the list of store wave.
WVDT	WAVE_DATA	SIGNAL	Get the wave data of store .
VKEY	VIRTUALKEY	SYSTEM	Set the virtual key.

1.3. IEEE 488.2 Common Command Introduction

IEEE standard defines the common commands used for querying the basic information of the instrument or executing basic operations. These commands usually start with "*" and the length of the keywords of the command is usually 3 characters.

1.1.5. CHDR

DESCRIPTION	This Command is used to change query command return format. SHORT parameter is return short format. LONG parameter is return long format. Off is that command header and parameter unit will not return.
COMMAND SYNTAX	Comm_HeaDeR <parameter> <parameter>:= {SHORT, LONG, OFF}
QUERY SYNTAX	Comm_HeaDeR?
RESPONSE FORMAT	SYNC <parameter>
EXAMPLE 1 CHDR LONG	Set query command format to long.
EXAMPLE 2	Read query command format.
return:	CHDR? COMM_HEADER LONG

1.1.6. OPC

DESCRIPTION	The *OPC (Operation Complete) command sets to true the OPC bit (bit 0) in the standard Event Status Register (ESR). The *OPC? query always responds with the ASCII character 1 because the device only responds to the query when the previous command has been entirely executed.
QUERY SYNTAX	*OPC?
RESPONSE FORMAT	*OPC 1

1.1.7. IDN

DESCRIPTION	The *IDN? Query causes the instrument to identify itself. The response comprises manufacturer, scope model, serial number, software version and firmware version.
QUERY SYNTAX	*IDN?
RESPONSE FORMAT	*IDN ,<device id>,<model>,<serial number>,<software version>,<firmware version> <device id>:= “SDG” is used to identify instrument. <model>:= A model identifier less than 14 characters. <serial number>:= A nine- or 10-digit decimal code . <software version>:= A serial numbers about software version. <firmware version>:= two digits giving the major release level followed by a period, then one digit giving the minor release level followed by a period and a single-digit update level (xx.y.z).
EXAMPLE 1	Reads version information. *IDN? return: *IDN SDG SDG1022,00-00-00-13-22,1.01.01.10R1,20.234.3. (return may differ form each version)

1.4. Output Command

DESCRIPTION Enable or disable the output of the [Output] connector at the front panel corresponding to the channel.

The query returns ON or OFF.

COMMAND SYNTAX <channel>: OUTPut <parameter>
 <channel>:={C1, C2}
 <parameter >:= {a parameter from the table below}

Parameters	Value	Description
ON	---	Turn on channel
OFF	---	Turn off channel
LOAD	<load>	Value of load

where: <load>:= {50(default unit is ohm), HZ}

QUERY SYNTAX <channel>: OUTPut?

RESPONSE FORMAT <channel>:OUTPut <load>

EXAMPLE 1 Turns on channel one.
 C1:OUTP ON

EXAMPLE 2 Reads channel one output state.
 C1:OUTP?
 return:
 C1:OUTP ON, LOAD, HZ

EXAMPLE 4 Set the load to 50 Ω
 C1:OUTP LOAD, 50

1.5. Basic Wave Command

DESCRIPTION Set or get basic wave parameters.

COMMAND SYNTAX <channel>:BaSicWaVe <parameter>
 <channel>:={C1, C2}

<parameter>:= {a parameter from the table below}

Parameters	Value	Description
WVTP	<type>	Type of wave
FRQ	<frequency>	Value of frequency. If wave type is Noise, you can't set this parameter.
AMP	<amplifier>	Value of amplifier. If wave type is Noise, you can't set this parameter.
OFST	<offset>	Value of offset. If wave type is Noise, you can't set this parameter.
SYM	<symmetry>	Value of symmetry. Only wave type is Ramp, you can set this parameter.
DUTY	<duty>	Value of duty cycle. Only Pulse and Duty can set this parameter.
PHSE	<phase>	Value of phase. If wave type is Noise, you can't set this parameter.
VAR	<variance>	Value of Noise wave Variance. Only wave type is Noise, you can set this parameter.
MEAN	<mean>	Value of Noise wave mean. Only wave type is Noise, you can set this parameter.

EXAMPLE 4 reads channel basic wave parameters from device.
 C1:BSWV?
 Return:
 C1: BSWV WVTP, SINE, FRQ, 1000, AMP, 3, OFST, 3, PHSE, 0

RELATED COMMANDS ARWV, BTWV, CFG, CPL, MDWV, SWWV

1.6. Modulate Wave Command

DESCRIPTION Set or get modulated wave parameters.

COMMAND SYNTAX <channel>:MoDulateWaVe <parameter>
 <channel>:={C1, C2}
 <parameter>:= {a parameter from the table below. }

Parameters	Value	Describe
STATE	<state>	Turn on or off modulated wave. Note if you want set or read modulate wave other parameter you must turn on the state first.
AM, SRC	<src>	AM signal source.
AM, MDSP	<mod wave shape>	AM modulation wave. . Only AM signal source is set to INT.
AM, FRQ	<am frequency>	AM frequency. Only AM signal source is set to INT.
AM, DEPTH	<depth>	AM deep. Only AM signal source is set to INT.
DSBAM, SRC	<src>	DSBAM signal source
DSBAM, MDSP	<mod wave shape>	DSBAM modulation wave. . Only AM signal source is set to INT.
DSBAM, FRQ	<dsbam frequency>	DSBAM frequency. Only AM signal source is set to INT.
FM, SRC	<src>	FM signal source

FM, MDSP	<mod wave shape>	FM modulation wave. Only FM signal source is set to INT.
FM, FRQ	<fm frequency>	FM frequency. Only FM signal source is set to INT.
FM, DEVI	<fm frequency offset>	FM frequency offset. Only FM signal source is set to INT.
PM, SRC,	<src>	PM signal source
PM, MDSP	<mod wave shape>	PM modulation wave. Only PM signal source is set to INT.
PM, FRQ	<pm frequency>	PM frequency. Only PM signal source is set to INT.
PWM, FRQ	<pwm frequency>	PWM frequency. Only carry wave is PULSE wave.
PWM, DEVI	<pwm devi>	Duty cycle deviation. Only carry wave is Pulse Wave.
PWM, MDSP	<mod wave shape>	PWM modulation wave. Only carry wave is PULSE wave.
PWM, SRC	<src>	PWM signal source.
PM, DEVI	<pm phase offset>	PM phase offset. Only PM signal source is set to INT.
ASK, SRC	<src>	ASK signal source.
ASK, KFRQ	<ask key frequency>	ASK key frequency. Only ASK signal source is set to INT.
FSK, KFRQ	<fsk frequency>	FSK frequency. Only FSK signal source is set to INT.
FSK, HFRQ	<fsk hop frequency>	FSK jump frequency
FSK, SRC	<src>	FSK signal source
CARR, WVTP	<wave type>	Value of carrier wave type.
CARR, FRQ	<frequency>	Value of frequency.
CARR, AMP	<amplifier>	Value of amplifier.
CARR, OFST	<offset>	Value of offset.
CARR, SYM	<symmetry>	Value of symmetry.

CARR, DUTY	<duty>	Value of duty cycle. Only Square can set this parameter.
CARR, PHSE	<phase>	Value of phase.
CARR DLY	<delay>	Value of delay.

Note: If Carrier wave is Pulse or Noise you can't set turn on modulate wave. If you want set AM, FM, PM, CARR and STATE the first parameter have to one of them.

where:

```

<state>:= {ON, OFF}
<src>:= {INT, EXT}
<mod wave shape>:= {SINE, SQUARE, TRIANGLE,
UPRAMP, DNRAMP, NOISE, ARB}
<am frequency>:= {0.002Hz to 20000Hz}
<deep>:= {0% to 120%}
<fm frequency>:= {0.002Hz to 20000Hz}
<fm frequency offset> := {0 to basic wave frequency / 2}
<pm frequency> := { 0.002Hz to 20000Hz}
<pm phase offset>:= {0° to 360° }
<pwm frequency>:= {0Hz to 4kHz }
<pwm devi>:= {depends on carry wave duty}
<ask key frequency>:= {0.002Hz to 20000Hz}
<fsk frequency>:= {0.002Hz to 50000Hz}
<fsk jump frequency>:= { the same witch basic wave
frequency}
<wave type>:= {SINE , SQUARE, RAMP, ARB, PULSE }
<frequency>:= { Default unit is "HZ". Minimum value is
1xe-6 HZ, maximal value depends on the version.}
<amplifier>:= {Default unit is "V". Channel one
minimum value 0.004V, Maximal is 6V. Channel two minimum
value 0.004V, Maximal is 20V. }
<offset>:= { Default unit is "V".}
<duty>:= { If wave type is square, range is from 20% to 80%.
If wave type is pulse, range is from 0.1% to 99.9%.}
<symmetry>:= { 0% to 100%}
<delay>:= {the maximal value is 2ks}

```

QUERY SYNTAX <channel>:MoDulateWaVe?
 <channel>:= {C1, C2}

RESPONSE FORMAT <channel>:MoDulateWaVe <parameter>

<parameter>:={return all parameter of the current modulate wave parameters.}

- EXAMPLE 1 set channel one modulation type to AM.
C1:MDWV AM
- EXAMPLE 2 Set modulation shape to AM, and set AM modulating wave type
to sine wave.
C1:MDWV AM, MDSP, SINE
- EXAMPLE 3 Reads channel one modulate wave parameters that STATE is
ON.
C1:MDWV?
return:
C1:MDWV
STATE, ON, AM, MDSP, SINE, SRC, INT, FRQ, 100HZ, DEPTH, 100, CARR,
WVTP, RAMP, FRQ, 1000HZ, AMP, 4V, OFST, 0V, SYM, 50
- EXAMPLE 3 Reads channel one modulate wave parameters that STATE is
OFF.
C1:MDWV?
return:
C1:MDWV STATE, OFF
- EXAMPLE 4 set channel one Fm frequency to 1000HZ
C1:MDWV FM, FRQ, 1000HZ
- EXAMPLE 5 set the Value of channel one carrier wave shape to SINE.
C1:MDWV CARR, WVTP, SINE
- EXAMPLE 6 set the Value of channel one carrier wave frequency to
1000hZ.
C1:MDWV CARR, FRQ, 1000HZ
- RELATED COMMANDS ARWV, BTWV, CFG, CPL, SWWV, BSWV

1.7. Sweep Wave Command

DESCRIPTION Set or get sweep wave parameters.

COMMAND SYNTAX <channel>:SweepWave <parameter>
 <channel>:={C1, C2}
 <parameter>:= {a parameter from the table below. }

Parameters	Value	Description
STATE	<state>	Turn on or off sweep wave. Note if you want set or read sweep wave other parameter you must turn on the state first.
TIME	<time>	Value of sweep time
STOP	<stop frequency>	Value of stop frequency
START	<start frequency>	Value of start frequency
TRSR	<trigger src>	Trigger source
TRMD	<trigger mode>	Value of trigger output. If TRSR is EXT, the parameter is invalid.
SWMD	<sweep mode >	Sweep way
DIR	<direction>	Sweep direction
EDGE	<edge>	Value of edge. Only TRSR is EXT, the parameter is valid.
MTRIG	<manual trigger>	Make the device once manual trigger. Only TRSR is MAN, the parameter is valid.
CARR, WVTP	<wave type>	Value of carrier wave type.
CARR, FRQ	<frequency>	Value of frequency.
CARR, AMP	<amplifier>	Value of amplifier.
CARR, OFST	<offset>	Value of offset.
CARR, SYM	<symmetry>	Value of symmetry.
CARR, DUTY	<duty>	Value of duty cycle. Only Square can set this parameter.
CARR, PHSE	<phase>	Value of phase.

Note: If Carrier wave is Pulse or Noise you can't set turn on modulate wave.

If you want set CARR and STATE the first parameter have to one of them.

where:

```

<state>:= {ON|OFF}
<time>:= {0.001S to 500S}

<stop frequency> :={ the same with basic wave frequency}
<start frequency> :={ the same with basic wave frequency}
<trigger src>:= {EXT, INT, MAN}
<trigger mode>:= {ON, OFF}
<sweep way>:= {LINE, LOG}
<direction>:= {UP, DOWN}
<edge>:= {ON, OFF}
<wave type>:= {SINE, SQUARE, RAMP, ARB}
<frequency>:= { Default unit is "HZ". Minimum value is
1xe-6 HZ, maximal value depends on the version.}
<amplifier>:= {Default unit is "V". Channel one
minimum value 0.004V, Maximal is 6V. Channel two minimum
value 0.004V, Maximal is 20V. }
<offset>:= { Default unit is "V". maximal value depends on
the maximal value depends on the version.}
<duty>:= { 20% to 80%. }
<symmetry>:= { 0% to 100%}

```

QUERY SYNTAX

```

<channel>:SWEEPWAve?
<channel>:= {C1, C2}

```

RESPONSE FORMAT

```

<parameter>:= {return all parameter of the current sweep
wave parameters.}

```

EXAMPLE 1

```

set channel one sweep time to 1 S.
C1:SWWV TIME, 1S

```

EXAMPLE 2

```

set channel one sweep stop frequency to 1000hz.
C1: SWWV STOP, 1000HZ

```

EXAMPLE 3

```

Reads channel one modulate wave parameters that STATE is
ON.
C2:SWWV?
Return:
C2:SWWV
STATE, ON, TIME, 1S, STOP, 100HZ, START, 100HZ, TRSR, MAN, TRMD, 0

```

FF, SWMD, LINE, DIR, UP, CARR, WVTP, SQUARE, FRQ, 1000HZ, AMP, 4V, OFST, 0V, DUTY, 50

EXAMPLE 4 Reads channel two modulate wave parameters that STATE is OFF.
 C2:SWWV?
 Return:
 C2:SWWV STATE, OFF

1.8. Burst Wave Command

DESCRIPTION Set or get burst wave parameters.

COMMAND SYNTAX <channel>:BurstWaVe <parameter>
 <channel>:={C1, C2}
 <parameter>:= {a parameter from the table below.}

Parameters	Value	Description
STATE	<state>	Turn on or off burst wave. Note if you want set or read burst wave other parameter you must turn on the state first.
PRD	<period>	When carrier wave is NOISE wave, you can't set it. When GATE was chosen, you can't set it. And only trig source is IN, you can set it.
STPS	<start phase>	When carrier wave is NOISE or PULSE wave, you can't set it.
GATE_NCYC	<gate ncycle>	When carrier wave is NOISE, you can't set it.
TRSR	<trigger>	When carrier wave is NOISE wave, you can't set it. When NCYC was chosen you can set it.
DLAY	<delay>	When carrier wave is NOISE wave, you can't set it. When NCYC was chosen you can't set it.
PLRT	<polarity>	When GATE was chosen you can set it. When carrier wave is NOISE, it is the only parameter.
TRMD	<trig mode>	When carrier wave is NOISE wave, you

		can't set it. When NCYC was chosen you can set it. When TRSR is set to EXT, you can't set is.
EDGE	<edge>	When carrier wave is NOISE wave, you can't set it. When NCYC was chosen and TRSR is set to EXT, you can set it.
TIME	<circle time>	When carrier wave is NOISE wave, you can't set it. When NCYC was chosen you can set it.
MTRIG		When TRSR's parameter be chosen to MAN, that it can be set.
CARR, WVTP	<wave type>	Value of carrier wave type.
CARR, FRQ	<frequency>	Value of frequency.
CARR, AMP	<amplifier>	Value of amplifier.
CARR, OFST	<offset>	Value of offset.
CARR, SYM	<symmetry>	Value of symmetry.
CARR, DUTY	<duty>	Value of duty cycle. Only Square can set this parameter.
CARR, PHSE	<phase>	Value of phase.
CARR, DLY	<carr delay>	Value of carrier wave delay. Only Carrier wave is Pusle ,the Value is valid.
CARR VAR	<variance>	Value of carrier wave variance. Only Carrier wave is Noise ,the Value is valid.
CARR MEAN	<mean>	Value of carrier wave mean. Only Carrier wave is Noise ,the Value is valid.

Note: If you want set CARR and STATE the first parameter have to one of them.

where:

- <state>:= {ON, OFF}
- <period>:= { Default unit is "S ". 1us to 500s }
- <start phase>:= {0 to 360}
- <gate ncycle>:= {GATE, NCYC}
- <trigger>:= {EXT, INT, MAN}
- <delay>:= { Default unit is "S". 0s to 500s }
- <polarity>:= {NEG, POS}
- <trig mode >:= {RISE, FALL, OFF}
- <edge>:= { RISE, FALL}
- <circle time > :={ 1cycle to 50000 cycle}
- <wave type>:= {SINE , SQUARE, RAMP, PULSE, NOISE, ARB}

<frequency>:= { Default unit is "HZ". Minimum value is 1xe-6 HZ, maximal value depends on the version.}
 <amplifier>:= {Default unit is "V". Channel one minimum value 0.004V, Maximal is 6V. Channel two minimum value 0.004V, Maximal is 20V. }
 <offset>:= { Default unit is "V". the maximal value depends on the version. }
 <duty>:= { If wave type is Square, range is from 20% to 80%
 If wave type is pulse, range is from 0.1% to 99.9%}
 <symmetry>:= { 0% to 100%}
 <carr delay>:= {Maximal is Pulse Period, minimum value is 0. Unit is S. }
 <variance>:= {0.4mv to 666.6mv}
 <mean>:= { the maximal value depends on the variance}

QUERY SYNTAX <channel>:BurstWaVe? <parameter>
 <parameter>:=<period>.....

RESPONSE FORMAT <channel>:BurstWaVe <type>|<state>|<period>.....

EXAMPLE 1 Set channel one burst wave period to 1S.
 C1:BTWV PRD, 1S

EXAMPLE 2 Set channel one burst wave delay to 0S
 C1:BTWV DLAY, 0S

EXAMPLE 3 Reads channel two burst wave parameters that STATE is ON.
 C2: BTWV?
 Return:
 C2:BTWV
 STATE, ON, PRD, 0. 01S, STPS, 0, TRSR, INT, TRMD, OFF, TIME, 1, DLAY
 , 2. 4e-07S, , GATE_NCYC, NCYC, CARR, WVTP, SINE, FRQ, 1000HZ, AMP
 , 4V, OFST, 0V, PHSE, 0

EXAMPLE 4 Reads channel two modulate wave parameters that STATE is OFF.
 C2: BTWV?
 Return:
 C2: BTWV STATE, OFF

1.9. Parameter Copy Command

DESCRIPTION copy channel data.

COMMAND SYNTAX `PArCoPy <destinat channle>, <src channle>`
`<destinat channle>:= {C1, C2}`
`<src channle>:= {C1, C2}`

Note: the parameters C1 and C2 must be set to device together. C1 is destination channel, C2 is source channel.

EXAMPLE 1 Copy parameters from channel one to channel two.
`PACP C2, C1`

RELATED COMMANDS ARWV, BTWV, CFG, CPL, MDWV, SWWV, BSWV

1.10. Arbitrary Wave Command

DESCRIPTION Change arbitrary wave type.

COMMAND SYNTAX `<channel>:ARbWaVe {INDEX, NAME}`
`<channel>:={C1, C2}`
`<index>: 2 to 60 (see blow table what the index number mean.)`
`<name>: see blow table.`

Index	Name	Index	Name	Index	Name	Index	Name	Index	Name
2	StairUp	13	LogRise	24	Gmonopuls	38	Gausswin	49	Acot
3	StairDown	14	Sqrt	25	Tripuls	39	Triang	50~60	User space
4	StarUD	15	Root3	26	Cardiac	40	blackmanharris		
5	PPulse	16	X ²	27	Quake	41	Bartlett		
6	NPulse	17	X ³	28	Chirp	42	Tan		
7	Trapezia	18	Sinc	29	Twotone	43	Cot		
8	UpRamp	19	Gussian	30	Snr	44	Sec		

9	DnRamp	20	Dlorentz	34	Hamming	45	Csc		
10	ExpFalls	21	Haversine	35	Hanning	46	Asin		
11	ExpRise	22	Lorentz	36	Kaiser	47	Acos		
12	LogFalls	23	Gauspuls	37	BlackMan	48	Atan		

Note: There is two ways to set current arbitrary wave. In one command must use one way to set arbitrary wave.

QUERY SYNTAX <channel>:ARbWaVe?
 <channel>:={C1, C2}

RESPONSE FORMAT <channel>:ARbWaVe <index>

EXAMPLE 1 Set StarUp arbitrary wave output by index.
 ARWV INDEX, 2

EXAMPLE 2 Reads system current wave.
 ARWV?
 Return:
 ARWV INDEX, 2, NAME, stairup

EXAMPLE 3 Set Atan arbitrary wave output by name.
 ARWV NAME, ATAN

RELATED COMMANDS BSWV

1.11. Phase Command

DESCRIPTION	Set or get phase parameters.
COMMAND SYNTAX	INVerT <parameter> <parameter>:= {OFF, ON}
QUERY SYNTAX	INVerT?
RESPONSE FORMAT	INVERT <parameter>
EXAMPLE 1	Set load to invert. INVT ON

1.12. Sync Command

DESCRIPTION	Set signal output from backward panel in phase with forward.
COMMAND SYNTAX	<channel>: SYNC <parameter> <channel>:={C1, C2} <parameter>:= {ON, OFF}
QUERY SYNTAX	<channel>:SYNC?
RESPONSE FORMAT	<channel>:SYNC <parameter>
EXAMPLE 1	Sync function on depend of channel one C1:SYNC ON
EXAMPLE 2	Reads channel one sync state. C1:SYNC? Return: C1:SYNC OFF\n

1.13. Configuration Command

DESCRIPTION	Changes system load data of power on.
COMMAND SYNTAX	Sys_CFG<parameter> <parameter>:= {DEFAULT, LAST}
QUERY SYNTAX	Sys_CFG?
RESPONSE FORMAT	Sys_CFG <parameter>
EXAMPLE 1	Set system load data of power on to last time data. SCFG LAST

1.14. Buzzer Command

DESCRIPTION	Turns on or off buzzer.
COMMAND SYNTAX	BUZZer <parameter> <parameter>:= {ON, OFF}
QUERY SYNTAX	BUZZer?
RESPONSE FORMAT	BUZZer <parameter>
EXAMPLE 1	Turns on buzzer. BUZZ ON

1.15. Screen Save Command

DESCRIPTION	Turns on or off Screen Save.
COMMAND SYNTAX	SCreen_SaVe <parameter> <parameter>:= {OFF, 1, 5, 15, 30, 60, 120, 300, Unit is minute}

QUERY SYNTAX SScreen_SaVe?

RESPONSE FORMAT SScreen_SaVe <parameter>

EXAMPLE 1 Set screen save time 5 minutes.

 SCSV 5

1.16. Clock Source Command

DESCRIPTION Set or get signal oscillator resource .

COMMAND SYNTAX ROscillator <parameter>
 <parameter>:= {INT, EXT }

QUERY SYNTAX ROscillator?

RESPONSE FORMAT ROsc <parameter>

EXAMPLE 1 Uses system clock source.

 ROsc INT

1.17. Frequency Counter

DESCRIPTION Set or get frequency counter.

COMMAND SYNTAX FreqCouNter {TRG, <value>, MODE,
 <value>, HFR, <value>, DEF , <value>}
 <value> = {see below table.}

QUERY SYNTAX FreqCouNter? {FRQ, DUTY, TRG, PW, NW, MODE, HFR}

RESPONSE FORMAT FreqCouNter <parameter>

Parameters	Value	Description
STATE	<state>	Turn on or off frequency counter
FRQ	<frequency>	Input signal frequency.

DUTY	<duty>	Input signal duty.
TRG	<trig level>	Input signal trig level.
PW	<positive width>	Input signal positive width.
NW	<negative width>	Input signal negative width.
MODE	<mode>	Frequency counter mode.
DEF	<default>	Set configuration to default.
HFR	<hfr>	Turn HFR on or off

Note: if you want to use this function, you must turn on frequency counter.

You can only set the mode, def and hfr of the list, the rest parameters only get value

where:

```

<state>:= {ON|OFF}
<frequency>:= {Input signal frequency.}
<duty>:= { Input signal duty.}
<trig level>:= { Input signal trig level.}
<positive width>:= { Input signal positive width.}
<negative width>:= { Input signal negative width.}
<mode>:= {AC|DC}
<default>:= { Set configuration to default.}
<hfr>:= {ON|OFF}
    
```

EXAMPLE 1 set trig level to 2v.
 FCNT TRG, 2v

EXAMPLE 2 get signal frequency.
 FCNT?
 Return:
 FCNT
 STATE, ON, FRQ, 0. 01HZ, DUTY, 0, TRG, 0V, PW, 0, NW, 0, MODE, AC, HFR, 0
 FF, FRQ, 0. 01HZ\n

1.18. Store list command

DESCRIPTION This command used to read the device wave data name if the store unit is empty, the command will return "EMPTY" string.

Note: M50~ M59 is user defined memory. The name will return what you defined. is you not defined arbitrary name will turn "EMPTY".

QUERY SYNTAX SToreList?

RESPONSE FORMAT STL M0, SINE, M1, noise, M2, STAIRUP, M3, STAIRDN, M4, STAIRUD, M5, PPULSE, M6, npulse, M7, TRAPEZIA, M8, UPAMP, M9, DNRAMP, M10, exp_fall, M11, exp_rise, M12, LOGFALL, M13, LOGRISE, M14, SQRT, M15, ROOT3, M16, x², M17, x³, M18, SINC, M19, gussian, M20, DLORENTZ, M21, haversine, M22, lorentz, M23, gauspuls, M24, gmonopuls, M25, tripuls, M26, cardiac, M27, quake, M28, chirp, M29, twotone, M30, snr, M31, EMPTY, M32, EMPTY, M33, EMPTY, M34, hamming, M35, hanning, M36, kaiser, M37, blackman, M38, gausswin, M39, triang, M40, blackmanharris, M41, barthannwin, M42, tan, M43, cot, M44, sec, M45, csc, M46, asin, M47, acos, M48, atan, M49, acot, M50, EMPTY, M51, EMPTY, M52, EMPTY, M53, EMPTY, M54, EMPTY, M55, EMPTY, M56, EMPTY, M57, EMPTY, M58, EMPTY, M59, EMPTY

EXAMPLE 1 Read device memory saved arbitrary data.

STL?

return:

STL M0, SINE, M1, noise, M2, STAIRUP, M3, STAIRDN, M4, STAIRUD, M5, PPULSE, M6, npulse, M7, TRAPEZIA, M8, UPAMP, M9, DNRAMP, M10, exp_fall, M11, exp_rise, M12, LOGFALL, M13, LOGRISE, M14, SQRT, M15, ROOT3, M16, x², M17, x³, M18, SINC, M19, gussian, M20, DLORENTZ, M21, haversine, M22, lorentz, M23, gauspuls, M24, gmonopuls, M25, tripuls, M26, cardiac, M27, quake, M28, chirp, M29, twotone, M30, snr, M31, EMPTY, M32, EMPTY, M33, EMPTY, M34, hamming, M35, hanning, M36, kaiser, M37, blackman, M38, gausswin, M39, triang, M40, blackmanharris, M41, barthannwin, M42, tan, M43, cot, M44, sec, M45, csc, M46, asin, M47, acos, M48, atan, M49, acot, M50, WAVE4, M51, 44, M52, EMPTY, M53, EMPTY,

M54, EMPTY, M55, EMPTY, M56, EMPTY, M57, EMPTY, M58, EMPTY, M59, EMPTY

1.19. Get arbitrary wave data command

DESCRIPTION The command used to change user defined memory unit arbitrary wave data.

COMMAND SYNTAX WaVe_DaTa <address>,<parameter>
 <address>:= {M50~M59}
 <parameter>:= {a parameter from the table below. }

Parameters	Value	Description
WVNM	<wavename>	arbitrary wave name
TYPE	<type>	Arbitrary wave type .Note the value have to be set to 5.
LENGTH	<length>	Arbitrary wave data Length. It have to be set to "32KB"
FREQ	<frequency>	Arbitrary wave frequency. It have to be set.
AMPL	<amplifier>	Value of amplify. It has to be set.
OFST	<offset>	Value of offset. It has to be set.
PHASE	<phase>	Value of phase. It has to be set.
WAVEDATA	<wavedata>	Wave data . It has to be set.

Not: All parameters must to be set in one command. If not, command will not execute successfully.

QUERY SYNTAX WaVe_DaTa

RESPONSE FORMAT WaVe_DaTa <parameter>

EXAMPLE Read device memory saved arbitrary data.

WVDT M50?

return:

WVDT POS, M51, WVNM, WAVE02, LENGTH, 32KB, TYPE, 5, WAVEDATA,\x00?\x03\x00\x06\x00\t\x00\f\x00\x0f\x00\x12\x00\x15\x00\x19\x00\x1c\x00\x1f\x00"\x00%\x00(\x00+\x0

0\<x002\x005\x008\x00;\>\x00A\x00E\x00H\x00K\x00N\x00Q\x00T\x00W\x00[\x00^\x00a\x00d\x00g\x00j\x00m\x00q\x00t\x00w\x00z\x00}\x00\x80\x00\x83\x00\x87\x00\x8a\x00\x8d\x00\x90\x00\x93\x00\x96\x00\x99\x00\x9d\x00\xa0\x00\xa3\x00\xa6\x00\xa9\x00\xac\x00\xaf\x00\xb3\x00\xb6\x00\xb9\x00xbc\x00xbf\x00xc2\x00xc5\x00xc9\x00\xcc\x00\xcf\x00\xd2\x00\xd5\x00\xd8\x00\xdb\x00\xdf\x00\xe2\x00\xe5\x00\xe8\x00\xeb\x00\xee\x00\xf1\x00\xf4\x00\xf8\x00\xfb\x00\xfe\x00\x01\x01\x04\x01\|a\x01\|n

\x01\x0e\x01|x11|x01|x14|x01|x17|x01|x1a\x01|x1d\x01

\x01\$\x01'\x01*\x01-\x010\x013\x016\x01:\x01=\x01@\x01C\x01F\x01I\x01L\x01P\x01S\x01V\x01Y\x01|\x01_\x01b\x01f\x01i\x01l\x01o\x01r\x01u\x01x\x01{\x01|x7f\x01|x82\x01|x85\x01|x88\x01|x8b\x01|x8e\x01|x91\x01|x95\x01|x98\x01|x9b\x01|x9e\x01|xa1\x01|xa4\x01|xa7\x01|xab\x01|xae\x01|xb1\x01|xb4\x01|xb7\x01|xba\x01|xbd\x01|xc0\x01|xc4\x01|xc7\x01|xca\x01|xcd\x01|xd0\x01|xd3\x01|xd6\x01|xda\x01|xdd\x01|xe0\x01|xe3\x01|xe6\x01|xe9\x01|xec\x01|xf0\x01|xf3\x01|xf6\x01|xf9\x01|xfc\x01|xff\x01|x02\x02\x05\x02|t\x02|f\x02|x0f\x02|x12\x02|x15\x02|x18\x02|x1b\x02|x1f\x02"|x02%\x02(\x02+\x02.\x021\x025\x028\x02;\x02>\x02A\x02D\x02G\x02J\x02N\x02Q\x02T\x02W\x02Z\x02J\x02'\x02d\x02g\x02j\x02m\x02p\x02s\x02v\x02y\x02}|\x02\x80\x02\x83\x02\x86\x02\x89\x02\x8c\x02\x8f\x02\x92\x02\x96\x02\x99\x02\x9c\x02\x9f\x02|xa2\x02|xa5\x02|xa8\x02|xac\x02|xaf\x02|xb2\x02|xb5\x02|xb8\x02|xbb\x02|xbe\x02|xc1\x02|xc5\x02|xc8\x02|xcb\x02|xce\x02|xd1\x02|xd4\x02|xd7\x02|xda\x02|xde\x02|xe1\x02|x04\x02|x07\x02|x0a\x02|x0d\x02|x0f\x02|x04\x02|x07\x02|x0a\x02|x0d\x02|x00\x03\x03\x03\x06\x03|t\x03|r

\x03\x10\x03\x13\x03\x16\x03\x19\x03\x1c\x03\x1f\x03"'\x03&\x03)\x03,\x03/\x032\x035\x038\x03;\x03?\x03B\x03E\x03H\x03K\x03N\x03Q\x03T\x03X\x03[\x03^\x03a\x03d\x03g\x03j\x03m\x03q\x03t\x03w\x03z\x03}|\x03\x80\x03\x83\x03\x86\x03\x8a\x03\x8d\x03\x90\x03\x93\x03\x96\x03\x99\x03\x9c\x03\x9f\x03|xa2\x03|xa6\x03|xa9\x03|xac\x03|xaf\x03|xb2\x03|xb5\x03|xb8\x03|xbb\x03|xbf\x03|xc2\x03|xc5\x03|xc8\x03|xcb\x03|xce\x03|xd1\x03|xd4\x03|xd8\x03|xdb\x03|xde\x03|xe1\x03|x04\x03|x07\x03|x0a\x03|x0d\x03|x0f\x03|x04\x03|x07\x03|x0a\x03|x0d\x03

\x04\x10\x04\x13\x04\x16\x04\x19\x04\x1c\x04\x1f\x04"'\x04%\x04)\x04,\x04/\x042\x045\x048\x04;\x04>\x04A\x04E\x04H\x04K\x04N\x04Q\x04T\x04W\x04Z\x04]|\x04a\x04d\x04g\x04j\x04m\x04p\x04s\x04v\x04y\x04}|\x04\x80\x04\x83\x04\x86\x04\x89\x04\x8c\x04\x8f\x04\x92\x04\x95\x04\x99\x04\x9c\x04\x9f\x04|xa2\x04|xa5\x04|xa8\x04|xab\x04|x04|x07\x04|x0a\x04|x0d\x04|x0f\x04|x04\x07\x04|x0a\x04|x0d\x04|x00\x05\x05\x05\x08\x05|t\x05|r

1.20. Virtual key command

DESCRIPTION The Command is to send key word to device.

COMMAND SYNTAX VirtualKEY VALUE, <value>, STATE, <sate>
 <value>:= {a parameter from the table below. }

<state>:=<0,1>(The "1" is effective to virtual value, and
 the "0" is useless)

KB_CHANNEL	33	KB_NUMBER_1	49
KB_FUNC1	28	KB_NUMBER_2	50
KB_FUNC2	23	KB_NUMBER_3	51
KB_FUNC3	18	KB_NUMBER_4	52
KB_FUNC4	13	KB_NUMBER_5	53
KB_FUNC5	8	KB_NUMBER_6	54
KB_SINE	34	KB_NUMBER_7	55
KB_SQUARE	29	KB_NUMBER_8	56
KB_RAMP	24	KB_NUMBER_9	57
KB_PULSE	19	KB_POINT	46
KB_NOISE	14	KB_NEGATIVE	43
KB_ARB	9	KB_LEFT	44
KB_MOD	15	KB_RIGHT	40
KB_SWEEP	16	KB_UP	45
KB_BURST	17	KB_DOWN	39
KB_STORE_RECALL	10	KB_OUTPUT1	153
KB_UTILITY	11	KB_OUTPUT2	152
KB_HELP	12	KB_KNOB_RIGHT	175
KB_NUMBER_0	48	KB_KNOB_LEFT	177

1.21. Index

*IDN *IDN
*OPC *OPC

A
ARWV ARBWAVE

B
BSWV BASIC_WAVE
BTWV BURSTWAVE
BUZZ BUZZER

C
CHCP CHANNEL_COPY
CHDR COMM_HEADER

D

DCWV DC_WAVE

I
INVT INVERT

M
MOD MODULATION
MDWV MODULATEWAVE

O
OUTP OUTPUT

P
PACP PARACOPY

R
ROSC ROSCILLATOR

S

SCFG SYSTEM_CONFIG
SY_FP SYSTEM_FRONT_PANEL

SCSV SCREEN_SAVE

STL STORE_LIST
SWE SWEEP
SYNC SYNC

W
WVDT WAVE_DATA